



Product Name

Cordless Drill

Product Code

MPGCS2400/20E

Articls Code

151-0001

Version

21-0060

Date

2022-06-23

MPGCS2400/20E SPARE PART LIST

| PART NO | ARTICLE CODE | DESCRIPTION | SPECIFICATION | WEARING PART | QTY REQUIRED | UNIT |
|---------|--------------|----------------------------|---------------|--------------|--------------|------|
| 1 | 151-0001-001 | Screw | | √ | 4 | pcs |
| 2 | 151-0001-002 | Starter Cover | | √ | 1 | pcs |
| 3 | 151-0001-003 | Starting Rope | | √ | 1 | pcs |
| 4 | 151-0001-004 | Starting Handle | | √ | 1 | pcs |
| 5 | 151-0001-005 | Rubber Sheathing | | √ | 1 | pcs |
| 6 | 151-0001-006 | Coil Spring | | √ | 1 | pcs |
| 7 | 151-0001-007 | Coil Spring Shell | | √ | 1 | pcs |
| 8 | 151-0001-008 | Starter Wheel | | √ | 1 | pcs |
| 9 | 151-0001-009 | Washer | φ5.3Xφ16X1 | √ | 1 | pcs |
| 10 | 151-0001-010 | Screw | | √ | 1 | pcs |
| 11 | 151-0001-011 | Cooling-Air Mask | | √ | 1 | pcs |
| 12 | 151-0001-012 | Oil Cap | | √ | 1 | pcs |
| 13 | 151-0001-013 | Oil Cap Packing Washer | | √ | 1 | pcs |
| 14 | 151-0001-014 | Oil Cap Retainer | | √ | 1 | pcs |
| 15 | 151-0001-015 | Screw | | × | 2 | pcs |
| 16 | 151-0001-016 | Igniter | | √ | 1 | pcs |
| 17 | 151-0001-017 | Nut | | × | 1 | pcs |
| 18 | 151-0001-018 | Flywheel | | √ | 1 | pcs |
| 19 | 151-0001-019 | Screw | | × | 2 | pcs |
| 20 | 151-0001-020 | Oil Seal Protector | | × | 1 | pcs |
| 21 | 151-0001-021 | Flameout Wire | | × | 1 | pcs |
| 22 | 151-0001-022 | Ground Strip | | × | 1 | pcs |
| 23 | 151-0001-023 | Flameout Switch | | × | 1 | pcs |
| 24 | 151-0001-024 | Screw | | × | 1 | pcs |
| 25 | 151-0001-025 | Screw | | × | 5 | pcs |
| 26 | 151-0001-026 | Screw | | × | 2 | pcs |
| 27 | 151-0001-027 | Anti-Vibration Cushion | | × | 3 | pcs |
| 28 | 151-0001-028 | Oil Seal | | × | 1 | pcs |
| 29 | 151-0001-029 | Left Anti-Vibration Block | | × | 1 | pcs |
| 30 | 151-0001-030 | Left Crankshaft Case | | √ | 1 | pcs |
| 31 | 151-0001-031 | HL Sheathing | | × | 1 | pcs |
| 32 | 151-0001-032 | Suction Nozzle | | × | 1 | pcs |
| 33 | 151-0001-033 | Suction Tube | | × | 1 | pcs |
| 34 | 151-0001-034 | Heat Insulation Tube | | × | 1 | pcs |
| 35 | 151-0001-035 | Shield Ring | | × | 1 | pcs |
| 36 | 151-0001-036 | Bearing | | × | 2 | pcs |
| 37 | 151-0001-037 | Crankshaft Case Gasket | | √ | 1 | pcs |
| 38 | 151-0001-038 | Dust Rubber Plate | | × | 1 | pcs |
| 39 | 151-0001-039 | Pin | | × | 2 | pcs |
| 40 | 151-0001-040 | Right Anti-Vibration Block | | × | 1 | pcs |
| 41 | 151-0001-041 | Right Crankshaft Case | | √ | 1 | pcs |
| 42 | 151-0001-042 | Spiked Bumper | | × | 1 | pcs |
| 43 | 151-0001-043 | Screw | | × | 2 | pcs |

MPGCS2400/20E SPARE PART LIST

| PART NO | ARTICLE CODE | DESCRIPTION | SPECIFICATION | WEARING PART | QTY REQUIRED | UNIT |
|---------|--------------|-------------------------|---------------|--------------|--------------|------|
| 44 | 151-0001-044 | Spring Base | | × | 1 | pcs |
| 45 | 151-0001-045 | Compressing Spring | | × | 1 | pcs |
| 46 | 151-0001-046 | Screw | | × | 2 | pcs |
| 47 | 151-0001-047 | Chain Catcher | | × | 1 | pcs |
| 48 | 151-0001-048 | Screw | | × | 1 | pcs |
| 49 | 151-0001-049 | Protecting Shield | | × | 1 | pcs |
| 50 | 151-0001-050 | Screw | | × | 1 | pcs |
| 51 | 151-0001-051 | Screw | | × | 2 | pcs |
| 52 | 151-0001-052 | Oil Filter | | × | 1 | pcs |
| 53 | 151-0001-053 | Oil Nozzle | | × | 1 | pcs |
| 54 | 151-0001-054 | Oil Seal | | × | 1 | pcs |
| 55 | 151-0001-055 | Aeration Nozzle | | × | 1 | pcs |
| 56 | 151-0001-056 | Aeration Nozzle Circlip | | × | 1 | pcs |
| 57 | 151-0001-057 | Aeration Nozzle Sponge | | × | 1 | pcs |
| 58 | 151-0001-058 | Oil Tube | | × | 1 | pcs |
| 59 | 151-0001-059 | Oil Pump Sponge | | × | 1 | pcs |
| 60 | 151-0001-060 | Oil Pump | | √ | 1 | pcs |
| 61 | 151-0001-061 | Screw | | × | 2 | pcs |
| 62 | 151-0001-062 | Oil Pump Cover Plate | | × | 1 | pcs |
| 63 | 151-0001-063 | Screw | | × | 3 | pcs |
| 65 | 151-0001-065 | Needle Bearing | K12x15x14 | × | 1 | pcs |
| 66 | 151-0001-066 | Oil Pump | | × | 1 | pcs |
| 67 | 151-0001-067 | Clutch Shell | | √ | 1 | pcs |
| 68 | 151-0001-068 | Clutch Washer | Φ10×Φ42×1.5 | √ | 1 | pcs |
| 69 | 151-0001-069 | Shoe Block Components | | √ | 1 | pcs |
| 70 | 151-0001-070 | Screw | | √ | 2 | pcs |
| 71 | 151-0001-071 | Tightener Cover | | √ | 1 | pcs |
| 72 | 151-0001-072 | Chain Guide | | √ | 2 | pcs |
| 73 | 151-0001-073 | Tightener Nut | | √ | 1 | pcs |
| 74 | 151-0001-074 | Tightener Screw | | √ | 1 | pcs |
| 75 | 151-0001-075 | Screw | | √ | 3 | pcs |
| 76 | 151-0001-076 | Brake Spring Cover | | √ | 1 | pcs |
| 77 | 151-0001-077 | Brake Belt | | √ | 1 | pcs |
| 78 | 151-0001-078 | Brake Control Rod | | √ | 1 | pcs |
| 79 | 151-0001-079 | Brake Spring | | √ | 1 | pcs |
| 80 | 151-0001-080 | Secondary Brake Spring | | √ | 1 | pcs |
| 81 | 151-0001-081 | Dust Shield | | √ | 1 | pcs |
| 82 | 151-0001-082 | Brake Cover | | √ | 1 | pcs |
| 83 | 151-0001-083 | Nut | | √ | 2 | pcs |
| 84 | 151-0001-084 | Front Guard Tube | | √ | 1 | pcs |
| 85 | 151-0001-085 | Front Guard Pin | | √ | 1 | pcs |
| 86 | 151-0001-086 | Secondary Pull-Rod | | √ | 1 | pcs |
| 87 | 151-0001-087 | Pin | | √ | 2 | pcs |

MPGCS2400/20E SPARE PART LIST

| PART NO | ARTICLE CODE | DESCRIPTION | SPECIFICATION | WEARING PART | QTY REQUIRED | UNIT |
|---------|--------------|----------------------------|---------------|--------------|--------------|------|
| 88 | 151-0001-088 | Main Pull-Rod | | √ | 1 | pcs |
| 89 | 151-0001-089 | Split Ring | | √ | 1 | pcs |
| 90 | 151-0001-090 | Chain brake | | √ | 1 | pcs |
| 91 | 151-0001-091 | Limiting Plate | | √ | 1 | pcs |
| 92 | 151-0001-092 | Washer | φ6Xφ18X1.5 | √ | 1 | pcs |
| 93 | 151-0001-093 | Limiting Pin | | √ | 1 | pcs |
| 94 | 151-0001-094 | Split Ring | | √ | 1 | pcs |
| 95 | 151-0001-095 | Brake Torsion Rod Spring | | √ | 1 | pcs |
| 96 | 151-0001-096 | Washer | φ6Xφ18X1.5 | √ | 1 | pcs |
| 97 | 151-0001-097 | Split Ring | | √ | 1 | pcs |
| 98 | 151-0001-098 | Rubber Washer | | √ | 1 | pcs |
| 99 | 151-0001-099 | Fuel Cap | | √ | 1 | pcs |
| 100 | 151-0001-100 | Fuel Cap Packing Washer | | x | 1 | pcs |
| 101 | 151-0001-101 | Fuel Cap Retainer | | x | 1 | pcs |
| 102 | 151-0001-102 | Fuel Tank | | x | 1 | pcs |
| 103 | 151-0001-103 | Washer | φ4Xφ8X0.5 | √ | 1 | pcs |
| 104 | 151-0001-104 | Screw | | x | 1 | pcs |
| 105 | 151-0001-105 | Trigger Torsion Rod Spring | | x | 1 | pcs |
| 106 | 151-0001-106 | Trigger | | x | 1 | pcs |
| 107 | 151-0001-107 | Pin | | x | 1 | pcs |
| 108 | 151-0001-108 | Fuel Filter | | x | 1 | pcs |
| 109 | 151-0001-109 | Fuel Tube | | x | 1 | pcs |
| 110 | 151-0001-110 | Primer bulb Cover | | √ | 1 | pcs |
| 111 | 151-0001-111 | Balancer Base | | x | 1 | pcs |
| 112 | 151-0001-112 | Balancer | | x | 1 | pcs |
| 113 | 151-0001-113 | Handle Cover | | x | 1 | pcs |
| 114 | 151-0001-114 | Trigger Controller | | x | 1 | pcs |
| 115 | 151-0001-115 | Double-Ended Pin | | x | 1 | pcs |
| 116 | 151-0001-116 | Anti-Vibration Cushion | | x | 2 | pcs |
| 117 | 151-0001-117 | Screw | | x | 2 | pcs |
| 118 | 151-0001-118 | Dust Cover | | x | 2 | pcs |
| 119 | 151-0001-119 | Crankshaft Components | | x | 1 | pcs |
| 120 | 151-0001-120 | Semicircular Key | | √ | 1 | pcs |
| 121 | 151-0001-121 | Needle Bearing Ring | | x | 1 | pcs |
| 122 | 151-0001-122 | Needle Bearing | k11×15×12.5 | x | 1 | pcs |
| 123 | 151-0001-123 | Piston Pin Ring | | x | 2 | pcs |
| 124 | 151-0001-124 | Piston | | x | 1 | pcs |
| 125 | 151-0001-125 | Piston Pin | | √ | 1 | pcs |
| 126 | 151-0001-126 | Piston Ring | | √ | 2 | pcs |
| 127 | 151-0001-127 | Cylinder Gasket | | √ | 1 | pcs |
| 128 | 151-0001-128 | Cylinder | | √ | 1 | pcs |
| 129 | 151-0001-129 | Throttle Lever Retainer | | √ | 1 | pcs |
| 130 | 151-0001-130 | Throttle Rod | | x | 1 | pcs |

MPGCS2400/20E SPARE PART LIST

| PART NO | ARTICLE CODE | DESCRIPTION | SPECIFICATION | WEARING PART | QTY REQUIRED | UNIT |
|---------|--------------|-------------------------------------|---------------|--------------|--------------|------|
| 131 | 151-0001-131 | Throttle Rod Anti-Shock Block | | x | 1 | pcs |
| 132 | 151-0001-132 | Accelerator Rod | | x | 1 | pcs |
| 133 | 151-0001-133 | Screw | | x | 2 | pcs |
| 134 | 151-0001-134 | Rubber Cushion | | x | 1 | pcs |
| 135 | 151-0001-135 | Air Filter Base | | x | 1 | pcs |
| 136 | 151-0001-136 | Screw | | x | 1 | pcs |
| 137 | 151-0001-137 | Dustproof Sponge | | x | 1 | pcs |
| 138 | 151-0001-138 | Carburetor | | x | 1 | pcs |
| 139 | 151-0001-139 | Copper Ring | | √ | 1 | pcs |
| 140 | 151-0001-140 | Idle Adjusting Guide | | x | 1 | pcs |
| 141 | 151-0001-141 | Air Intake Flange | | x | 1 | pcs |
| 142 | 151-0001-142 | Carburetor Support Gasket | | x | 1 | pcs |
| 143 | 151-0001-143 | Carburetor Support | | √ | 1 | pcs |
| 144 | 151-0001-144 | Underside Carburetor Support Gasket | | x | 1 | pcs |
| 145 | 151-0001-145 | Screw | | √ | 2 | pcs |
| 146 | 151-0001-146 | Air Intake Tube | | x | 1 | pcs |
| 147 | 151-0001-147 | Air Intake Tube Gasket | | √ | 1 | pcs |
| 148 | 151-0001-148 | Screw | | x | 2 | pcs |
| 149 | 151-0001-149 | Spark Plug | | x | 1 | pcs |
| 150 | 151-0001-150 | Air Filter Rubber Gasket | | √ | 1 | pcs |
| 151 | 151-0001-151 | Air Filter | | x | 1 | pcs |
| 152 | 151-0001-152 | Dustproof Paper Cushion | | √ | 1 | pcs |
| 153 | 151-0001-153 | Air Filter Cover | | √ | 1 | pcs |
| 154 | 151-0001-154 | Lock Nut Washer | | x | 1 | pcs |
| 155 | 151-0001-155 | Air Filter Lock Nut | | x | 1 | pcs |
| 156 | 151-0001-156 | Flameout Switch Base | | x | 1 | pcs |
| 157 | 151-0001-157 | Upper Cover Plate | | x | 1 | pcs |
| 158 | 151-0001-158 | Screw | | x | 5 | pcs |
| 159 | 151-0001-159 | Screw | | x | 4 | pcs |
| 160 | 151-0001-160 | Screw | | x | 2 | pcs |
| 161 | 151-0001-161 | Silencer Gasket | | x | 1 | pcs |
| 162 | 151-0001-162 | Silencer | | √ | 1 | pcs |
| 163 | 151-0001-163 | Screw | | √ | 2 | pcs |
| 164 | 151-0001-164 | Silencer Cap | | x | 1 | pcs |
| 165 | 151-0001-165 | Nut | | x | 2 | pcs |
| 166 | 151-0001-166 | Bar Cover | | √ | 1 | pcs |
| 167 | 151-0001-167 | Chain | | √ | 1 | pcs |
| 168 | 151-0001-168 | Bar | | √ | 1 | pcs |
| 169 | 151-0001-169 | Front Handle Assembly | | x | 1 | pcs |
| 170 | 151-0001-170 | Screw | | x | 4 | pcs |